

Active

Select an Active Surface

1. Press the **Power** button on the display, then select **Data > Active > Surface**. Select the surface file you want to be active on the main screen (Figure 2-51).




Figure 2-51: Select an Active Surface File



NOTICE

Surfaces can also be selected as active using the Context Pop-up menu. For more information, see “Set Active Surface” on page 6-16.

Select an Active Alignment

1. Press the **Power** button on the display, then tap **Data > Active > Alignment**.
2. Select the alignment file to be active on the main screen (Figure 2-52).




Figure 2-52: Select an Active Alignment File