








Unit	LED	Colour	State	Description	
Tersus David GNSS Receiver 	RTK	RED	ON	David30 in Fixed Solution	
			BLINKING	David30 in Float and DGPS Solution	
			OFF	David30 in other position types	
	SV	RED	ON	Normal State	
			BLINKING	David30 is searching for satellites	
	PWR	-	BLUE	ON	David30 is powered on
OFF			David30 is powered off		
Netcomm Wireless Modem 	 POWER	-	OFF	Power Off	
		GREEN	DOUBLE FLASH	Powering Up	
		GREEN	ON	Power On	
		ORANGE	ON	Power On in Recovery Mode	
	 Network	RED	SLOW FLASHING	Hardware Error	
		GREEN	ON	Connected via WWAN	
		GREEN	BLINKING	Traffic via WWAN	
		GREEN	SLOW FLASHING	Connecting PDP	
		ORANGE	ON	Registered Network	
		ORANGE	SLOW FLASHING	Registered Network	
		RED	SLOW FLASHING	SIM PIN Locked	
		RED	FAST FLASHING	SIM PUK Locked	
	 GPS/Customizable LED Indicator	RED	ON	Cant Connect / Device in "Configuration Mode"	
		-	OFF	GPS Function Disabled	
		RED	ON	GPS Function is enabled but no satellite is detected	
	 Signal Strength	ORANGE	FLASHING	Satellite detected, acquiring location	
		GREEN	ON	Satellite detected, location acquired	
		GREEN	ON	LTE Signal	
		ORANGE	ON	WCDMA Signal	
		RED	ON	GSM Signal	
	Serial to Ethernet Module 	PWR	RED	ON	Power supply is normal
				OFF	No Power supply or abnormal power supply
		Work	RED	BLINKING	Power is on and the Device is ready. System is booted up and running
TXN		RED	BLINKING	Serial Port is Transmitting data	
RXN		RED	BLINKING	Serial Port is Receiving data	



> SOLUTION READY

Advise | Enable | Support